

廠牌	型號	適用機型
JVC	BN-V101	GC-S5 ,
	BN-V107 / BN-V107B / BN-V107S BN-V107SU / BN-V107U / BN-V114 BN-V114B / BN-V114S / BN-V114SU BN-V114U / BN-V114US	GR-DVP1 , GR-DVP3 , GR-DVP3 ST , GR-DVP3U , GR-DVP5 , GR-DVP5EG , GR-DVP7 , GR-DVP7A , GR-DVP7A-BK , GR-DVP7A-SL , GR-DVP7ED , GR-DVP7EG , GR-DVP7EK , GR-DVP7SH , GR-DVP7U , GR-DVP7USI , GR-DVP8 , GR-DVP9 , GR-DVP9U , GR-DVP9US , GR-DX100 , GR-DX100EK , GR-DX106 , GR-DX107 , GR-DX25 , GR-DX25E , GR-DX25EK , GR-DX27 , GR-DX28 , GR-DX300 , GR-DX300E , GR-DX300K , GR-DX300U , GR-DX300US , GR-DX307 , GR-DX307US , GR-DX317 , GR-DX35 , GR-DX35E , GR-DX35K , GR-DX37 , GR-DX45 , GR-DX48 , GR-DX55 , GR-DX55E , GR-DX57 , GR-DX67 , GR-DX75 , GR-DX75US , GR-DX76 , GR-DX77 , GR-DX77US , GR-DX78 , GR-DX95 , GR-DX95E , GR-DX95K , GR-DX95U , GR-DX95US , GR-DX97 , GR-DX97US ,
	BN-V306 / BN-V306U / BN-V312 BN-V312U	GR-DVM407 , GR-DVM76 , GR-DVM76U , GR-DVM79 , GR-DVM96 , GR-DVM96U , GR-DVX400 , GR-DVX400EG , GR-DVX407 , GR-DVX407EG , GR-DVX408 , GR-DVX507 , , GR-DVX507EG , GR-DVX509 , GR-DVX600K , GR-DVX6K , GR-DVX707 , GR-DVX707EG , GR-DVX709 ,
	BN-V408 / BN-V408-H / BN-V408U BN-V416 / BN-V416-H / BN-V416U BN-V428 / BN-V428U	GR-DVA101 , GR-DVA11K , GR-DVA20K , GR-DVA22K , GR-DVA30K , GR-DVA33K , GR-DVF505U , GR-DVL100 , GR-DVL100EG , GR-DVL100U , GR-DVL1020 , GR-DVL105 , GR-DVL105U , GR-DVL107 , GR-DVL107EG , GR-DVL107U , GR-DVL108 , GR-DVL109 , GR-DVL1170 , GR-DVL120 , GR-DVL120U , GR-DVL140 , GR-DVL145 , GR-DVL145EG , GR-DVL150 , GR-DVL150EG , GR-DVL150EK , GR-DVL155 , GR-DVL157 , GR-DVL157EG , GR-DVL157EK , GR-DVL160 , GR-DVL160EG , GR-DVL160EK , GR-DVL166 , GR-DVL167 , GR-DVL167EG , GR-DVL200 , GR-DVL200U , GR-DVL205 , GR-DVL207 , GR-DVL210 , GR-DVL210U , GR-DVL220 , GR-DVL220U , GR-DVL257 , , GR-DVL300 , GR-DVL300U , GR-DVL300EG , GR-DVL300U , GR-DVL305 , GR-DVL305U , GR-DVL307 , GR-DVL307U , GR-DVL308 , GR-DVL309 , GR-DVL310 , GR-DVL310U , GR-DVL315 , GR-DVL315U , GR-DVL317 , GR-DVL317U , GR-DVL320 , GR-DVL320U , GR-DVL322 , GR-DVL323 , GR-DVL326 , GR-DVL355 , GR-DVL357 , GR-DVL365 , GR-DVL365EG , GR-DVL367 , GR-DVL367EG , GR-DVL400 , GR-DVL400U , GR-DVL410 , GR-DVL420 , GR-DVL450 , GR-DVL500 , GR-DVL500U , GR-DVL505 , GR-DVL505U , GR-DVL507 , GR-DVL507U , GR-DVL510 , R-DVL510U , GR-DVL512 , GR-DVL512U , GR-DVL515 , GR-DVL515U , GR-DVL517 , GR-DVL517U , GR-DVL520 , GR-DVL520U , GR-DVL522 , GR-DVL522U , GR-DVL525 , GR-DVL555 , GR-DVL557 , GR-DVL567 , GR-DVL600 , GR-DVL600U , GR-DVL607 , GR-DVL610 , GR-DVL707 , GR-DVL707U , GR-DVL710 , GR-DVL715 , GR-DVL720 , GR-DVL720U , GR-DVL722 , GR-DVL725 , GR-DVL725U , GR-DVL728 , GR-DVL765 , GR-DVL767 , GR-DVL767EG , GR-DVL800 , GR-DVL800U , GR-DVL805 , GR-DVL805U , GR-DVL810 , GR-DVL815 , GR-DVL815U , GR-DVL817 , GR-DVL817U , GR-DVL820 , GR-DVL820U , GR-DVL822U , GR-DVL828 , GR-DVL865 , GR-DVL867 , GR-DVL867EG , GR-DVL910 , GR-DVL915 , GR-DVL915U , GR-DVL920 , GR-DVL920U , GR-DVL925 , GR-DVL970 , GR-DZ7 , GR-DZ7US , GR-HD1U , GR-HD1US , GR-PD1 , GR-VF1 , GY-DV300U , GY-HD100 , JY-HD10US , JY-VS200U , GR-HD1 ,
	BN-V507 / BN-V507B / BN-V507U BN-V514 / BN-V514U	GR-DVM50 , GR-DVM50U , GR-DVM55 , GR-DVM55U , GR-DVM70 , GR-DVM70U , GR-DVM75 , GR-DVM75U , GR-DVM80 , GR-DVM80U , GR-DVM90 , GR-DVM90U , GR-DVX10 , GR-DVX10EG , GR-DVX4 , GR-DVX40 , GR-DVX40A , GR-DVX44 , GR-DVX44EG , GR-DVX48 , GR-DVX49 , GR-DVX5K , GR-DVX7 , GR-DVX70 , GR-DVX77 , GR-DVX78 , GR-DVX8 , GR-DVX80 , GR-DVX88 , GR-DVX88EG , GR-DVX9 , GR-DVX90 , GR-DVX9EG .
	BN-VF707 / BN-VF707U / BN-VF714 BN-VF714U / BN-VF714US / BN-VF733 BN-VF733U / BN-VF733US / LY34647-002B	GR-D239 , GR-D240 , GR-D244US , GR-D246 , GR-D247 , GR-D250AC , GR-D250U , GR-D250US , GR-D270 , GR-D270AC , GR-D270U , GR-D270US , GR-D271 , GR-D271US , GR-D275 , GR-D275U , GR-D275US , GR-D29 , GR-D290 , GR-D290AC , GR-D290AH , GR-D290US , GR-D295 , GR-D295US , GR-D320 , GR-D320EX , GR-D328EF , GR-D340 , GR-D340EX , GR-D350AC , GR-D350U , GR-D350US , GR-D360 , GR-D360EX , GR-D370 , GR-D370AC , GR-D370EX , GR-D370U , GR-D370US , GR-D371US , GR-D375U , GR-D375US , GR-D390U , GR-D390US , GR-D395US , GR-D396US , GR-D640 , GR-D640EX , GR-D650AC , GR-D650EX , GR-DF420 , GR-DF425 , GR-DF430 , GR-DF430US , GR-DF450 , GR-DF450U , GR-DF450US , GR-DF470US , GR-DF540 , GR-DF550U , GR-DF550US , GR-DF565 , GR-DF570US , GR-X5E , , GR-X5US , GZ-D240 , GZ-D270 , GZ-DF420 , GZ-DF470 , GZ-MG20 , GZ-MG20U , GZ-MG20US , GZ-MG21 , GZ-MG21EX , GZ-MG21US , GZ-MG26 , GZ-MG27 , GZ-MG27EX , GZ-MG27US , GZ-MG30 , GZ-MG30U , GZ-MG30US , GZ-MG31 , GZ-MG35US , GZ-MG37 , GZ-MG37EX , GZ-MG37US , GZ-MG40US , GZ-MG505AC , GZ-MG505B , GZ-MG505S , GZ-MG505US , GZ-MG50US , GZ-MG60 , GZ-MG67EX , GZ-MG67US , GZ-MG70US , gz-mg70tw , GZ-MG77EX , GZ-MG77US , GZ-MG37 , GZ-MG40 , GZ-MG47 , GZ-MG50 , GZ-MG57 , GZ-MG67 , GZ-MG70 , GZ-MG77 , GZ-MG505 , GR-D250 , GR-D270 , GR-D350 , GR-D370 , GR-D650 , GR-DF550 , GR-DF570 , , GR-DF590 , GR-DF470 , GR-X5 , GZ-MG50TW ,
	BN-VM200 / BN-VM200U / LY34416-001B	GZ-MC100 , GZ-MC100EK , GZ-MC100EX , GZ-MC100US , GZ-MC200 , GZ-MC200E , GZ-MC200EX , GZ-MC200US , GZ-MC500 , GZ-MC500EK , GZ-MC500EX , GZ-MC500US ,
	BN-VF808 / NB-VF815 / BN-VF823	GZ-MG130 , GZ-MG135 , GZ-MG150 , GZ-MG155 , GZ-MG255 , GZ-MG275 , GZ-MG555 , GZ-MG575 , GZ-MG740 , GZ-MG730 , GZ-MG530 , GZ-MG330 , GZ-MG360 , GZ-MG465 , GZ-MG435 , GZ-MG430 , GZ-MG630 , GZ-MG840 , GZ-MG880 , GZ-HD310ATW , GZ-HD7 , GZ-HD3 , GZ-HD6 , GZ-HD5 , GZ-HD10 , GZ-HD320 , GZ-HD300 , GZ-HD40 , GZ-HD30 , GR-D720 , GR-D725 , GR-D740 , GR-D745 , GR-D750 , GR-D760 , GR-D770 , GR-D771 , GR-D775 , GR-D790 , GR-D796 , GR-D850 , GZ-HM200 , GY-HM100 , GZ-MS130 , GZ-MS120 , GZ-MS100