

廠牌	型號	適用機型
RICOH	DB-20 (FNP-80)	CAPLIO RR1, RDC-6000, RDC-7, RDC-7S, RDC-i500,
	DB-30 (FNP-100)	RDC-i700
	DB-40 (FNP-60)	Caplio 300G, Caplio 400G wide, Caplio G4, Caplio G4wide, Caplio RR10, Caplio RR30, Caplio RR300, Caplio G3,
	DB-43 (FNP-120)	Caplio 500G, Caplio G3, Caplio G4, Caplio GX, Caplio GX8, Caplio Pro G3, Caplio R330, Caplio RR10, Caplio RR30, Caplio RX, Caplio 500SE, Caplio 500Gwide,
	DB-50 (KLIC-8000)	Caplio R1, Caplio R1S, Caplio R1V, Caplio R2, Caplio RZ1,
	DB-60、65 (S005E)	Caplio R3, Caplio R30, Caplio R4, Caplio R40, Caplio R5, GR Digital, GR Digital II, GR D, GR D II, GRD III, GX100, GX200,
	DB-70 (S008E)	Caplio R6, Caplio R7, Caplio R8, Caplio R10, CX1, CX2
	DB-80 (D-Li78)	Caplio R50,
	DB-90(FNP-95)	GXR
	DB-100 (LI-50B)	CX-3