

廠牌	型號	適用機型
SANYO	DB-L10 (Li-12B)	DSC-J1 , DSC-MZ3 , DSC-J2 , DSC-AZ3
	DB-L20	Xacti DMX-C1 , Xacti DMX-C4 , Xacti DMX-C5 , Xacti DMX-C6 , VPC-C40 , VPC-CA6 , Xacti CA65 , VPC-CG6 , DMX- CG65 , DMX-CG9 , DMX-CA8 , VPC-CA9 , Xacti DSC-E1 , Xacti DSC-E6 , Xacti VPC-E7 , Xacti DSC- E60 , Xacti DSC-J4 C1 , C4 , C5 , C6 , C40 , CA6 , CA65 , CG6 , CG65 , CG9 , CA8 , E1 , E6 , E7 , E60 , J4 ,
	DB-L30 (NP-700)	Xacti VPC-A5 ,
	DB-L40	Xacti DMX-HD1 , Xacti VPC-HD1A , DMX-HD2 , DMX-HD700 , DMX-HD800 ,
	DB-L50(KLIC-5001)	DMX-HD1000 , DMX-HD1010 , DMX-HD2000 , FH11 , TH1 , FH1 , WH1
	DB-L80 (D-Li88)	Xacti DMX-CG110 , H90
	DB-L90	SH1 , SH11